<u>CONTACT</u>

Pilatus Aircraft

<u>Pilatus B4</u>

Pilatus B4 Data Sheet Pilatus B4 maintenance & Repair Manual

Status	Subject	Detail	Reference Information	TNS
М	Canopy catch	Fit limiting cable	SB 1001	
М	Crotch strap	Fouls rudder cables	SB 1002	
М	Aileron	Bell crank pin fouling	SB 1003	
	Control systems	Lubrication	SL 101	
М	Seat latch pins fouling	Serial numbers 1→140	SL 102	
М	Gear down lock cracks	Fit thicker locking plate		<u>07/76</u>
	Rudder cables	Escape from keyholes guides - wire or tape around guides		<u>12/76</u>
	Elevator drive rods	Rivets loose in fittings		<u>12/85</u>
М	Airbrake system	Fit stops & check rivets for looseness	AD 86-041, SB 1004	<u>04/86</u>
М	Drag spar pin improperly engaged	Inspect & modify if necessary		<u>08/88</u>
М	Drag spar bushes	To be secured may fall out of de-rigged gliders		<u>10/75</u> & <u>10/90</u>
	Fin to fuselage joint corrosion	Inspect for paint cracks		<u>04/96</u>
R	Tailplane	Tailplane mounting inspection following H/Landing, Ground loop or severe turbulence	BGA 018/05/2001 issue 2	<u>06/01</u>
М	Flying controls	Inspection of CC support (B4-PC11, 11A, 11AF)	AD 2004-491, SB 1005	<u>04/03</u>

Pilatus B4 In Service Reports (Advisory)

Status	Subject	Detail	Reference Information	TNS
I	Landing gear	Operating arm tubular rivet failed		<u>1/2009</u>
I	Structures	Exfoliation corrosion found on wing spar root area		<u>2-2012</u>